



vtech[®]

Instruction Manual

Zoo Jamz[®]

Tiger Rock Guitar[™]




91-003913-003 

INTRODUCTION

Thank you for purchasing the **Zoo Jamz Tiger Rock Guitar™!**

Play along to rock, blues and country melodies and sing-along songs about animals. Switch between acoustic, electric or distorted electric guitar sounds by turning the knob or moving the slider.



INCLUDED IN THE PACKAGE

- Zoo Jamz Tiger Rock Guitar™
- Instruction Manual

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please keep this Instruction Manual as it contains important information.


ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

Unlock the Packaging Locks




- ① Rotate the packaging locks counterclockwise several times.
- ② Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.

- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.



PRODUCT FEATURES

1. Off/Mode Selector

Slide the **Off/Mode Selector** to either Guitar Fun or Animal Band mode to power on the unit or to change mode. Slide the selector back to the Off position to turn the unit Off.




2. Low/High Volume Buttons

Press the **Low Volume Button**  to lower the volume. Press the **High Volume Button**  to increase the volume. After powering the unit off and on again, you may need to adjust the volume.







3. Light-Up Buttons

Press the eight **Light-Up Buttons** to create your own music with acoustic, clean electric, distorted electric guitar or animal sounds. The lights will flash with the music and sing-along songs.




4. Guitar Sound Switch

Switch the **Guitar Sound Switch** to select Acoustic , Clean Electric  or Distorted Electric guitar  sounds.




5. Music Genre Switch

Switch the **Music Genre Switch** to choose between Rock , Blues  or Country  music genres.




6. String Slider

Move the **String Slider** to play sound effects and melodies.




7. Whammy Bar

Move the **Whammy Bar** to hear special guitar sound effects.



8. Music Button

Press the **Music Button** to play melodies.




9. Stop Button

Press the **Stop Button** to stop the current responses.



10. Tiger Button


In Guitar Fun mode, press this button to hear Tiger's roar and to play guitar sounds on the eight **Light-Up Buttons**. In Animal Band mode, press this button to jam the Tiger's roar over the melody, or to hear sing-along songs about the Tiger.



11. Elephant, Bear, Parrot and Frog Buttons



In Guitar Fun mode, press these buttons followed by the eight **Light-Up Buttons** to create music with animal sounds. In Animal Band mode, press these buttons to play the melodies in animal sounds, or to hear sing-along songs about the animals.



AUTOMATIC SHUT-OFF

To preserve battery life, the **Zoo Jamz Tiger Rock Guitar™** will automatically shut off after several minutes without input. The unit can be turned on again by moving the **Off/Mode Selector** to any mode.


NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Guitar Fun

Move the **Off/Mode Selector** to the second position to enter this mode. Press the eight **Light-Up Buttons** to create your own music. Switch the **Guitar Sound Switch** or press an **Animal Button** to select the guitar or animal sound you would like to use to create music. If no melody or song is playing, move the **String Slider** to play a few seconds of music. Keep moving the bar to keep the music playing. Move the **Whammy Bar** to hear fun sounds.



2. Animal Band

Move the **Off/Mode Selector** to the third position to enter this mode. Press any **Animal Button** to hear sing-along songs. After pressing an **Animal Button**, press the **Music Button** to hear the melody played in the selected animal sound. If no melody or song is playing, move the **String Slider** to play a few seconds of music in the selected animal's sound. Keep moving the slider to keep the music playing. Move the **Whammy Bar** to hear fun sounds.



SONG LYRICS

Song 1

My stripes are black and they're unique.
A group of tigers is called a streak.
I play the guitar and roam the land.
I like to make music with my friends in a band.
We're all different, and that's pretty cool.
We play with everyone; it's our only rule.

Song 2

Oh do you know how tigers roar?
How tigers roar? How tigers roar?
Oh do you know how tigers roar?
Come on and roar with me!
ROAR!

Oh yes, I know how tigers roar.
How tigers roar. How tigers roar.
Oh yes, I know how tigers roar.
Because I'm a tiger!
ROAR!

Song 3

The elephant joined the band,
The elephant joined the band,
The elephant joined the band,
To play her trumpet trunk.

Her trumpet goes brrr brrr!
Her trumpet goes brrr brrr!
She gives her ears a shake, shake, shake,
And then stomps on the ground.

Song 4

Elephants are really big!
Elephants are really strong!
Elephants are the biggest,
Animals on land!

Elephants are really big!
Elephants are really strong!
Elephants are the biggest,
Animals on land!

Song 5

Parrots have many colors,
Red, green, yellow and blue.
Some parrots like to talk,
(Hello! How are you?)
Well I'm feeling fine, and hope you are too.
Oh! Parrots have many colors,
(What colors do you like?)
Red, green, yellow and blue! Yeah!

Song 6

My friend is a parrot named Perry.
His mom is a parrot named Mary.
His brother is a parrot named Larry.
His papa is a parrot named Barry.
Perry, Mary, Larry, Barry.
A feathery parrot family.

Song 7

Jump, jump, jump,
Went the frog, went the frog, went the frog.
Jump, jump, jump,
Went the frog,
From branch, to tree, to stump.

Jump, jump, jump,
Went the frog, went the frog, went the frog.
Jump, jump, jump,
Went the frog,
From branch, to tree, to stump.

Song 8

Ribbit ribbit says froggy frog.
Ribbit ribbit says frog from a log.
Frog can live in both water or on land.
Frog likes to ribbit at the music stand.

Ribbit ribbit says froggy frog.
Ribbit ribbit says frog from a log.
Frog's tongue catches food better than his hand.
Frog likes to ribbit at the music stand.

Song 9

The bear went over the mountain,
The bear went over the mountain,
The bear went over the mountain,
To see what she could see.
The other side of the mountain,
The other side of the mountain,
The other side of the mountain,
Was all that she could see.

Song 10

Big brown bear,
Big brown bear,
Bears have lots of fur,
Lots of furry fur,
Bears really like to eat a lot,
Fruit, grass, and fish, why not?
Seeds and berries for dessert,
Oh big brown bear.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5378
Product Name: Zoo Jamz Tiger Rock Guitar™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

CAN ICES-3 (B)/NMB-3(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty



TM & © 2020 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003913-003 (US)