

## 540600-Learn & Grow Farm (\$29.99)

AW Release Date: 21/03/29

Purpose: Printing version

IM Size: 101 X 127MM

C&P Designer/Leader: David Ye / Alisa Huang

US Designer: Jordan Wrobleske-Baumann

Game/PT Designer: Zoe Gao / Tramy Chau

**vtech**<sup>®</sup>

# Instruction Manual


## Learn & Grow Farm<sup>™</sup>



# INTRODUCTION

Thank you for purchasing the **Learn & Grow Farm™!**


Have fun with farming! Place any of the animals on one of the two Talking Points to hear phrases and sounds. Three light-up buttons introduce time concepts and daily routines. Set up your farm with a stable, tractor, animals and more, and let your imagination grow!



# INCLUDED IN THE PACKAGE



One silo back



One silo front



One silo base




One stable roof



One stable wall



One stable base



One windmill



One windmill bracket




One windmill base



One field piece



One barn roof



One barn



(M)

One weather vane



(N)

One butterfly slider




(O)

One mouse toggle




(P)

One barn base



(Q)

Two gates




(R)

One seesaw seat



(S)

One seesaw base



(T)

Four fences



(U)

One cart



(V)

One tractor



One farmer



One electronic panel



One bale of hay



One bundle of  
firewood



Four farm animals (Cow, Donkey, Chicken and Cat)

- Label sheet
- Quick Start Guide

### **WARNING**

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

### **NOTE**

Please save this Instruction Manual as it contains important information.

### **ATTENTION**

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.


### **NOTE**

Il est conseillé de sauvegarder ce manuel d'instructions car il comporte des informations importantes.

# INSTRUCTIONS

## Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



### **WARNING:**

Adult assembly required for battery installation.  
Keep batteries out of reach of children.

### **ATTENTION :**

Les piles ou accumulateurs doivent être installés par un adulte.  
Tenir les piles ou accumulateurs hors de portée des enfants.

## **IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.



### **RECHARGEABLE BATTERIES:**

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.



# LABEL APPLICATION

Please securely stick the labels to the playset as indicated on the following pages:





# ASSEMBLY INSTRUCTIONS



With the **Learn & Grow Farm™**, safety comes first. To ensure your child's safety, adult assembly is required.

## SMALL COMPONENT ASSEMBLY

1. Insert **(A)** into **(B)**, then **(C)** as shown. You will hear a click sound to indicate the pieces are secure.






2. Insert **(E)** into **(D)**, then insert into **(F)**. You will hear a click sound to indicate the pieces are secure. Please note that they cannot be detached once connected.






3. Insert **G** into **H**, then insert into **I**. You will hear a click sound to indicate the pieces are secure. Please note they cannot be detached once connected. Lastly, join **J** to **I** as shown.



4. First, attach **K** to **L**. Second, insert **M**, **N** and **O** into **L** as shown. Then, insert **L** into **P**. You will hear a click sound to indicate the base is secure. Please note they cannot be detached once connected. Lastly, attach the two **Q** pieces to **L** as shown.



5. Finally, assemble the play pieces. Insert **(R)** into **(S)**. Connect the **(T)** pieces to each other. Attach the **(U)** to **(V)** as shown.



6. Join the assembled **Silo**, **Barn**, **Stable** and **Windmill** together as shown.




Once you've completed the above steps, you are ready to play! Refer to the product image on the cover page of the manual for one way to set up the **Learn & Grow Farm™**.

## PRODUCT FEATURES

### 1. On/Off/Volume Selector

To turn the unit **On**, slide the **On/Off/Volume Selector** to either volume setting. You will hear a song, a phrase and a sound effect. To turn the unit **Off**, slide the **On/Off/Volume Selector** to the **Off ●** position.



## 2. Automatic Shut-Off

To preserve battery life, the **Learn & Grow Farm™** will automatically turn **Off** after approximately 40 seconds without input. The unit can be turned on again by pressing any button.

### NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

## ACTIVITIES


### 1. Electronic Panel

Insert the **Electronic Panel** into the **Barn** to enter Play Time mode. Remove the **Electronic Panel** from the **Barn** to enter Farm Time mode. To turn the **Electronic Panel** into a shower, flip it 90 degrees. Pull the **Shower Lever** to hear fun sound effects and give the **Farm Animals** a pretend shower.



### 2. Light-up Buttons

Press the **Light-up Buttons** to learn time concept and colors, and hear sing-along songs and melodies. The lights will flash with sounds.



### 3. Talking Point Circle

Place one of the **Farm Animals** or the **Farmer** on the Talking Point Circle to hear the Farmer say friendly phrases. Place a figure on either Talking Point to hear even more unique phrases. The lights will flash with the sounds.



#### 4. Talking Point Rectangle

Place one of the **Farm Animals** or the **Farmer** on the Talking Point Rectangle. The Talking Point will recognize the animals and teach animals names, sounds, and facts. Place a figure on either Talking Point to hear even more unique phrases. The lights will flash with the sounds.



## MELODIES

1. Bingo
2. Red River Valley
3. I Want to Go Back to Michigan, Down on the Farm
4. Oats, Peas, Beans, and Barley Grow
5. Old MacDonald Had a Farm
6. Peas Porridge Hot
7. Sweet and Low
8. Hey Diddle, Diddle
9. Good Morning, Merry Sunshine
10. Frère Jacques
11. Twinkle, Twinkle, Little Star
12. Brahms' Lullaby

## SONG LYRICS

### Song 1

On the farm every day is busy  
There's always something to do

### Song 2

There's lots of room to work and play,  
Here on our farm each day

# CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the unit is not working properly, install a brand new set of batteries.

## IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

## NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **CAUTION**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Supplier's Declaration of Conformity**

47 CFR § 2.1077 Compliance Information

|                    |   |
|--------------------|---|
| Trade Name:        | VTech®  |
| Model:             | 5406  |
| Product Name:      | Learn & Grow Farm™  |
| Responsible Party: | VTech Electronics North America, L.L.C.                       |
| Address:           | 1156 W. Shure Drive, Suite 200<br>Arlington Heights, IL 60004 |
| Website:           | vtechkids.com   |

**THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.**



**Visit our website for more  
information about our products,  
downloads, resources and more.**

***vtechkids.com***  
***vtechkids.ca***

Read our complete warranty policy online at  
***vtechkids.com/warranty***  
***vtechkids.ca/warranty***

