

vtech®

Instruction Manual



Smart Monster Truck



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Toot-Toot Drivers® Smart Monster Truck**. Come on! Let's play.

This remote-free **Toot-Toot Drivers** truck uses IR sensors that detect your child and reacts accordingly!

2 modes of play encourage interaction, light up roof button triggers vehicle facts, phrases & songs with fun movement & stop & go buttons teach colours, safety & trigger left, right, forward & spinning!



INCLUDED IN THIS PACKAGE

- One VTech® Toot-Toot Drivers® Smart Monster Truck




- One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please save this Instruction Manual as it contains important information.

PACKAGING LOCK REMOVAL




- ① Rotate the packaging locks 90 degrees anticlockwise.
- ② Pull out the packaging locks.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the Smart Monster Truck. Use a screwdriver to loosen the screw.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 4 new AA (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used. not use damaged batteries.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheeled bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:




Visit www.recyclenow.com to see a list of collection points near you.


In Australia & New Zealand:

Check with you local council for kerbside collections.


PRODUCT FEATURES

1. ON/OFF/Mode Switch

To turn the unit **ON**, slide the **ON/OFF/Mode Switch** to the **Learn Mode** () or the **Interact Mode** () position. You will hear a song, a phrase and a sound effect. To turn the unit **OFF**, slide the slide the **ON/OFF/Mode Switch** to the **OFF** () position.



WARNING: For your child's safety, only use the Smart Monster Truck on the floor. Do not roll the truck on your clothing, body or hair while the motorised truck is turned on. If something gets caught in the truck's wheels while the motor is on, lift the truck up so it is no longer touching your child or slide the mode selector switch to the off position to turn the motor off. Adult supervision required.



2. AUTOMATIC SHUT-OFF

To preserve battery life, the **Smart Monster Truck** will automatically shut-off after approximately 50 seconds without input. The unit can be turned on again by pressing any button.

NOTE: This product is in Try-Me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play. If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Slide the **ON/OFF/Mode Switch** to the Learn Mode (📖) or Interact Mode position (🔗) to turn the unit on. You will hear a sing-along song, fun phrase and a sound effect. The lights will flash and the truck will move in different ways while making fun sounds.



2. Press the **GO BUTTON** to hear playful fun phrases and sounds. The lights will flash and the smart truck will move in different ways while making fun sounds.



3. Press the **STOP BUTTON** to hear playful fun phrases and sounds. The lights will flash with the sounds.



4. Press the **LIGHT UP ROOF BUTTON** to hear sing-along songs, playful fun phrases and sounds. The light will flash and the smart truck will move in different ways while making fun sounds. In **Interact Mode**, press the **LIGHT UP ROOF BUTTON** when the monster truck is moving, to hear playful fun phrases or short tunes. The lights will flash with the sounds and the smart truck will stop.



5. The smart truck is equipped with special sensors at the front. Move near the sensors to activate them and see the smart truck move away or dance and respond with playful phrases, music and sounds. The lights will flash with the sounds.

SONG LYRICS

SONG 1

Toot-Toot Drivers

Toot-Toot Drivers

I'm a Toot-Toot Drivers monster truck

Ready to play with you (Toot-Toot)

My tyres get me around all day long

Let's Go! Go! and see (Toot-Toot)

SONG 2

Driving here, driving there

I love to drive anywhere!

SONG 3

Turning left, turning right,

Putting on a great show,

Racing back and forth

1,2,3, here we go!

MELODY LIST

1. Aiken Drum
2. Bingo
3. Humpty Dumpty
4. Jack Be Nimble
5. One, Two, Buckle My Shoe
6. Hey Diddle Diddle
7. Hickory Dickory Dock
8. Rockin' Robin
9. The Entertainer
10. Boys and Girls Go Out to Play

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing VTech products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

Product Warranty / Consumer Guarantees

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
CAN ICES-003(B)/NMB-003(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

